VP5300 Cert failed and firmware update

Step 1: **Connect the VP5300 which shows "Cert Failed" to the PC**

Step 2: **Unzip this file and execute**



You should see this, please wait for 5-6 minutes.



Step 3: **You will see the update completely message at the end.**

Certificate Update Utility

```
VP6300:024T519926  Main Firmware: Sent block 1152 of 1174
VP6300:024T519926  Main Firmware: Sent block 1153 of 1174
VP6300:024T519926  Main Firmware: Sent block 1154 of 1174
VP6300:024T519926  Main Firmware: Sent block 1155 of 1174
VP6300:024T519926  Main Firmware: Sent block 1156 of 1174
VP6300:024T519926  Main Firmware: Sent block 1157 of 1174
VP6300:024T519926  Main Firmware: Sent block 1158 of 1174
VP6300:024T519926  Main Firmware: Sent block 1159 of 1174
VP6300:024T519926  Main Firmware: Sent block 1160 of 1174
VP6300:024T519926  Main Firmware: Sent block 1161 of 1174
VP6300:024T519926  Main Firmware: Sent block 1162 of 1174
VP6300:024T519926  Main Firmware: Sent block 1163 of 1174
VP6300:024T519926  Main Firmware: Sent block 1164 of 1174
VP6300:024T519926  Main Firmware: Sent block 1165 of 1174
VP6300:024T519926  Main Firmware: Sent block 1166 of 1174
VP6300:024T519926  Main Firmware: Sent block 1167 of 1174
VP6300:024T519926  Main Firmware: Sent block 1168 of 1174
VP6300:024T519926  Main Firmware: Sent block 1169 of 1174
VP6300:024T519926  Main Firmware: Sent block 1170 of 1174
VP6300:024T519926  Main Firmware: Sent block 1171 of 1174
VP6300:024T519926  Main Firmware: Sent block 1172 of 1174
VP6300:024T519926  Main Firmware: Sent block 1173 of 1174
VP6300:024T519926  Main Firmware: Sent block 1174 of 1174
VP6300:024T519926   Applying Firmware Update....
VP6300:024T519926   Firmware Update Successful
VP6300:024T519926  K81 Loaded Successfully. v1.01.003.0432
VP6300:024T519926  VP6300 Firmware Update Completed Successfully.
VP6300:024T519926  Update From Archive Completed Successfully
```