

USER MANUAL

SecuRED Encrypted Magstripe Reader OPOS Reference Guide

80128503-001

Rev A. 9/9/13

Revision History

Revision	Date	Description	By
А	9/9/2013	Initial Release	СН

Table of Contents

1.	Description	6
2.	Methods, Properties and Events of SecuRED	7
2.1.	Methods of MSR	7
2.2.	Properties of MSR	11
2.3.	Events of MSR	22
3.	Programming Examples	24
3.1.	Visual C++ 6.0 Programming Example	24
3.2.	Visual Basic 6.0 Programming Example	26
3.3.	Visual Studio 2005/2008 C# Programming Example	29
4.	Result Code/Error Code List	32

ID TECH SOFTWARE COPYRIGHT NOTICE

Copyright 2010-2013 International Technologies & Systems Corporation. All rights reserved. ID TECH is a registered trademark of International Technologies & Systems Corporation. Value through Innovation, Spectrum is trademarks of International Technologies & Systems Corporation.

ID TECH SOFTWARE LICENSE AGREEMENT

ID TECH ("LICENSOR") IS WILLING TO LICENSE THIS SOFTWARE TO YOU ONLY IF YOU ACCEPT ALL OF THE TERMS IN THIS LICENSE AGREEMENT. PLEASE READ THE TERMS CAREFULLY BEFORE YOU AGREE BECAUSE YOU WILL BE BOUND BY THE TERMS OF THIS AGREEMENT. IF YOU DO NOT AGREE TO THESE TERMS, LICENSOR WILL NOT LICENSE THIS SOFTWARE TO YOU.

Ownership of the Software

1. The Licensor software program ("Software") and any accompanying written materials are owned by Licensor [or its suppliers] and are protected by United States copyright laws, by laws of other nations, and by international treaties.

Grant of License

2. Licensor grants to you the right to use the Software in conjunction with an ID TECH product. You may load one copy into permanent memory of one computer and may use that copy only on that same computer.

Restrictions on Use and Transfer

3. You may not copy the Software, except that (1) you may make one copy of the Software solely for backup or archival purposes, and (2) you may transfer the Software to a single hard disk provided you keep the original solely for backup or archival purposes. You may not copy the written materials.

4. You may permanently transfer the Software and any accompanying written materials (including the most recent update and all prior versions) if you retain no copies and the transferee agrees to be bound by the terms of this Agreement. Such a transfer terminates your license. You may not rent or lease the Software or otherwise transfer or assign the right to use the Software, except as stated in this paragraph.

5. You may not reverse engineer, decompile, or disassemble the Software.

Limited Warranty

6. If used in conjunction with an ID TECH product, Licensor warrants that the Software will perform substantially in accordance with the accompanying written materials for a period of 90 days from the date of your receipt of the Software. Any implied warranties on the Software are limited to 90 days. Some states and territories do not allow limitations on duration of an implied warranty, so the above limitation may not apply to you.

7. LICENSOR DISCLAIMS ALL OTHER WARRANTIES, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT, WITH RESPECT TO THE SOFTWARE AND ANY ACCOMPANYING WRITTEN MATERIALS. This limited warranty gives you specific legal rights. You may have others, which vary from state to state.

8. LICENSOR'S ENTIRE LIABILITY AND YOUR EXCLUSIVE REMEDY SHALL BE REPLACEMENT OF THE SOFTWARE THAT DOES NOT MEET LICENSOR'S LIMITED WARRANTY. Any replacement Software will be warranted for the remainder of the original warranty period or 30 days, whichever is longer.

9. This Limited Warranty is void if failure of the Software has resulted from modification, accident, abuse, or misapplication.

10. IN NO EVENT WILL LICENSOR BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY LOSS OF PROFITS, LOST SAVINGS, OR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF YOUR USE OR INABILITY TO USE THE SOFTWARE. Because some states do not allow the exclusion or limitation of liability for consequential or incidental damages, the above limitation may not apply to you.

11. This Agreement is governed by the laws of the state of California.

12. If you have any questions concerning this Agreement or wish to contact Licensor for any reason, please write: ID TECH, 10721 Walker Street, Cypress, CA 90630 or call (714) 761-6368.

13. U.S. Government Restricted Rights. The Software and documentation are provided with Restricted Rights. Use, duplication, or disclosure by the Government is subject to restrictions set forth in subparagraph (c)(1) of The Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 or subparagraphs (c)(1)(ii) and (2) of Commercial Computer Software - Restricted Rights at 48 CFR 52.227-19, as applicable. Supplier is ID TECH, 10721 Walker Street, Cypress, CA 90630.

1. Description

The documentation describes the properties, methods, and events of the ID TECH SecuRED MSR OPOS component. The component includes two parts: a Control Object running on the upper level, which is an ActiveX control, and a Service Control running on the lower level, which is an OLE automation server. The properties, methods, and events are exposed by the Control Object. When the Control Object is imported into your project as an ActiveX control, you will see all the properties, methods, and events.

For different interface devices, OPOS drivers may be different. For USB HID Keyboard interfaces device, the standard keyboard should not be pressed when swiping cards, otherwise the card data will be wrong, MSR OPOS Driver will display a warning dialog and the data will be discarded.

The SecuRED MSR device can't support hot plug when OPOS driver is in the Open state. If you have already pulled out the device in Open state, close driver and reopen can use again.

For the same interface SecuRED MSR devices, the OPOS supports only one device for use on a computer. In other words: at the same time, the OPOS only allows to connect one device.

If the SecuRED MSR Device has been authenticated, the application should cancel the authentication before close the OPOS. Otherwise, the device will stay in the authentication state 120 seconds.

Target Device: ID TECH SecuRED USB-HID, USB-KB interface

Platform: Microsoft Windows 8, Windows 7, Vista, XP, 2000, 98. Service Object and Control Object: Service Object Version: 1.13.309 Control Object Version: 1.13.001 Dll File Version: 3.0.9

2. Methods, Properties and Events of SecuRED

This section describes methods, properties and events for the SecuRED Encrypted MSR.

2.1. Methods of MSR

These function declarations may be different when the Control Object (OPOSMSR.OCX) is imported into your application project. Please refer to the UnifiedPOS Specification for more detailed information on the Control Object.

1) Open

 Syntax
 LONG Open (BSTR DeviceName); DeviceName: For USB HID interface: "IDTECH_ SECURED _USBHID" For USB KB interface: "IDTECH_ SECURED _USBKB"

 Remarks
 Call to open a device for subsequent I/O.

 Support?
 Yes

Description This method finds more parameters in the Windows Register Tables on key or sub keys.

For USB HID interface:

HKEY_LOCAL_MACHINE\Software\OLEforRetail\ServiceOPOS\MSR\ IDTECH_ SECURED _USBHID\ CONNECTOR

Key value name: USBHID Key value: "usbhidConn.dll" Key value name: CONNECTOR Key value: "USBHID/0acd/2810" First field USBHID specify the type of the connector. 0acd is the USB device vendor ID, 2810 is the reader product ID.

For USB KB interface:

HKEY_LOCAL_MACHINE\Software\OLEforRetail\ServiceOPOS\MSR\ IDTECH_ SECURED _USBKB\ CONNECTOR

Key value name: USBKB Key value: "usbkbConnector.dll" Key value name: CONNECTOR Key value: "USBKB/0acd/2820" First field USBKB specify the type of the connector. 0acd is the USB device vendor ID, 2820 is the reader product ID.

2) ClaimDevice Added in Release 1.5 Syntax LONG ClaimDevice (LONG *Timeout*); **Remarks** Call this method to request exclusive access to the device. Many devices require an application to claim them before they can be used. *Release 1.0 - 1.4* in releases prior to 1.5, this method is named Claim.

Support? Yes

3) CheckHealth

Syntax LONG CheckHealth (LONG Level);

Remarks Called to test the state of a device.

Support? Yes

Description When select CH_INTERNAL, check the SO response, if not it tells that there is something wrong with the device. CheckHealthText property will be "Internal HCheck: Successful"

When select CH_EXTERNAL, SO will return the firmware version of the SecuRED device, if reading the firmware version is successful. CheckHealthText property will be "External HCheck: Successful" + firmware version information. If Not Responding, CheckHealthText property will be "External HCheck: Not Responding".

When select CH_INTERACTIVE, SO will display a dialog, which include firmware version and swiping card. And it can display the "Real data" of the card; include Start Sentinel and End Sentinel. CheckHealthText property will show "External HCheck:: HCheck: Complete", after the dialog is closed.

4) ClearInput

Syntax	LONG ClearInput ();
Remarks	Called to clear all device input that has been buffered.
Support?	Yes

5) DirectIO

SyntaxLONG DirectIO (LONG Command, LONG* pData, BSTR* pString);RemarksCall to communicate directly with the Service Object.Support?NoDescriptionIn the current, it implemented incompletely. We will improve it in the

Description In the current, it implemented incompletely. We will improve it in the next release.

6) Release	eDevice Added in Release 1.5
Syntax	LONG ReleaseDevice ();
Remarks	Call this method to release exclusive access to the device.
	Release 1.0 – 1.4
	In releases prior to 1.5, this method is named Release .
Support?	Yes
7) Close	
Syntax	LONG Close ():

Remarks Called to release the device and its resources.

Support? Yes

8) ResetStatistics Added in Release 1.8 Syntax LONG ResetStatistics(BSTR m_StatisticsBuffer); Remarks Called to Resets the defined resettable statistics in a device to zero. Support? No

9) RetrieveStatistics Added in Release 1.8

Syntax	LONG RetrieveStatistics(BSTR* m_pStatisticsBuffer);
Remarks	Called to Retrieves the requested statistics from a device.
Support?	No

10) UpdateStatistics Added in Release 1.8

Syntax	LONG UpdateStatistics(BSTR m_StatisticsBuffer);
Remarks	Called to Updates the defined resettable statistics in a device.
Support?	No

11) CompareFirmwareVersion

Syntax	LONG CompareFirmwareVersion(BSTR m_FirmwareFileName,			
	long* m_pResult);			
Remarks the device.	Called to compare the firmware version with current firmware version of			
Support?	No			

12) UpdateFirmware

Syntax	LONG UpdateFirmware(BSTR m_FirmwareFileName);
Remarks	Called to update current firmware.
Support?	No

13) ClearInputProperties

Syntaxvoid ClearInputProperties();RemarksSets all data properties that were populated as a result of firing aDataEvent or ErrorEvent back to their default values.

Support? Yes

14) WriteTracks

Syntax	long WriteTracks(LPCTSTR data, long timeout)				
Remarks	Sets all data properties that were populated as a result of firing a				
DataEvent of	r ErrorEvent back to their default values.				
Support?	No				

15) AuthenticateDevice

Syntax	long AuthenticateDevice (LPCTSTR response)			
Remarks	To authenticate a device, the application first calls the			

retrieveDeviceAuthenticationData method to retrieve a challenge token from the device. The application then typically passes this token to another entity that has special knowledge of a shared secret and is able to create a proper response token. This response token is then passed as the response parameter to this method and the service uses it to validate the authentication request. If this method succeeds, the device enters the authenticated state and the service sets the DeviceAuthenticated property to true.

For SecuRED: The response needs to be 16 bytes in length. And it should be transmitted as a Hex string. Example, 0xAB 0x00 0x09 is converted to "AB0009".

Support? Yes

16) DeauthenticateDevice

Syntax long DeauthenticateDevice (LPCTSTR response)

- **Remarks** This method is used to deauthenticate a device that is currently in the authenticated state (DeviceAuthenticated = true). The token is typically generated by passing the challenge retrieved from the retrieveDeviceAuthenticationData method to an entity that has special knowledge of a shared secret. If this method succeeds the service sets DeviceAuthenticated to false and enqueues a StatusUpdateEvent with status value set to MSR_SUE_DEVICE_DEAUTHENTICATED. For SecuRED: The response needs to be 16 bytes (when Encryption Algorithm is 3DES) or 8 bytes (when Encryption Algorithm is AES) in length. And it should be transmitted as a Hex string. Example, 0xAB 0x00 0x09 is converted to "AB0009".
- Support? Yes

17) RetrieveCardProperty

Syntax long RetrieveCardProperty (**BSTR** *Name*, **BSTR** **Value*)

Remarks Retrieves the value of specific parsed properties from the last card swiped.

Support? Yes

18) RetrieveDeviceAuthenticationData

- **Syntax long RetrieveDeviceAuthenticationData** (LPCTSTR *challenge*)
- **Remarks** Applications call this method to retrieve a challenge token that will subsequently be used to generate response tokens that will be passed to the authenticateDevice and deauthenticateDevice methods. The challenge token is typically sent to another entity that has special knowledge of a shared secret that is required to generate the proper response token(s).

For SecuRED: The challenge is always 26 bytes in length. And it will be transmitted as a Hex string. Example, 0xAB 0x00 0x09 is converted to "AB0009".

Support? Yes

19) UpdateKey

Syntax	long UpdateKey (BSTR Key, BSTR KeyName)
Remarks	Provides a new encryption key to the device. It is used only for those
	encryption algorithms in which new key values are sent to the terminal
	as a field in standard messages from the host.
Support?	NO

2.2. Properties of MSR

Please refer to the UnifiedPOS Specification for detailed information.

NOTE: CO --- Control Object

SO --- Service Object

AP or App --- the abbreviation of Application.

Name	Туре	Mutability	Use	Description	Support?
			After		
DeviceControlDescri	String	read-only		Identify the Control Object and	Yes
ption				the company that produced it	
DeviceControlVersio	int32	read-only		Hold the Control Object version	Yes
n				number.	
DeviceServiceDescrip	String	read-only	open	Identify the Service Object	Yes
tion				supporting the device and the	
				company that	
				produced it	
DeviceServiceVersion	int32	read-only	open	Hold the Service Object version	Yes
				number.	
PhysicalDeviceDescri	string	read-only	open	Identify the device and any	Yes
ption				pertinent information about it.	
PhysicalDeviceName	string	read-only	open	Identify the device and any	Yes
				pertinent information about it.	

Property Group1---Description

Property Group2---Control

Name	Туре	Mutability	Use	Description	Support?
			After		
Claimed	Boolean	read-only	open	SecuRED must be claimed for	Yes
				exclusive use before access its	
				methods and properties, and	
				before any events to be fired. It	
				is initialized to FALSE by the	
				Open method. It is set to TRUE	
				after the method Claim is	
				successfully called.	
AutoDisable	Boolean	read-write	open	When TRUE, as soon as an event	Yes
				DataEvent is received, then	
				DeviceEnabled is automatically	
				to FALSE. It is initialized to	
				FALSE by the Open method.	
DeviceEnabled	Boolean	read-write	open&	When FALSE, SecuRED has	Yes
			claim	been disabled and any subsequent	
				input will be discarded (No	
				DataEvent could be received even	
				if the card is swiped). It is	
				initialized to FALSE by the Open	

				method.	
FreezeEvents	boolean	read-write	open	When TRUE, events are not	Yes
				required to be delivered and will	
				be held by SO until events are	
				unfrozen. It is initialized to	
				FALSE by the Open method.	
DataEventEnabled	boolean	read-write	open	When TRUE, a DataEvent or	Yes
				ErrorEvent will be delivered	
				immediately when had. (Of	
				course, <i>FreezeEvents=FALSE</i>	
				and DeviceEnabled=TRUE is a	
				prerequisite). It is initialized to	
				FALSE by the Open method.	
CapPowerReportin	int32	read-only	open	Identifies the reporting	No
g				capabilities of the device about	
				Power. It seems that SecuRED	
				doesn't support in the hardware.	
PowerNotify	int32	read-write	open	Contains the type power	No
				notification selection made by the	
				Application. is initialized to	
				OPOS_PN_DISABLED by the	
				Open method.	
PowerState	int32	read-only	open	Contains the current power	No
				condition. It seems that	
				SecuRED doesn't support in the	
				hardware.	
State	int32	Read-only		Contains the current state of the	Yes
				Control. It can be set to one of the	
				four	
				Values: Closed, Idle, Busy, or	
				Error.	
DataCount	int32	Read-only	open	Holds the number of queued	Yes
				DataEvents remained in the	
				queue.	
CheckHealthText	string	read-only	open	Holds the results of the most	Yes
				recent call to the CheckHealth	
				method. Before the first	
				CheckHealth method call, its	
				value is uninitialized.	

Property Group3---Track Control

Name	Туре	Mutability	Use	Description	Support?
			After		
CapISO	boolean	read-only	open	If TRUE, SecuRED	Yes
				supports ISO cards.	
CapJISOne	boolean	read-only	open	If TRUE, SecuRED	No
				supports JIS Type-I	
				cards. JIS-I cards are a	
				superset of ISO cards.	
				Therefore, if	
				CapJISOne is true, it is	
				implied that CapISO is	
				also TRUE.	
CapJISTwo	boolean	read-only	open	If TRUE, SecuRED	No
				supports JIS type-II	
				cards.	
CapTransmitSentinels	boolean	read-only	open	If TRUE, SecuRED is	Yes
				able to transmit the start	
				and end sentinels. e.g.	
				start sentinel could be	
				'%' or ';', and stop	
				sentinel could be '?'.	
DecodeData	boolean	read-write	open	If TRUE, each byte of	Yes
				track data properties is	
				mapped from its original	
				encoded bit sequence (as	
				it exists on the magnetic	
				card) to its	
				corresponding decoded	
				ASCII bit sequence.	
ParseDecodeData	boolean	read-write	open	When TRUE, the	Yes
				decoded data contained	
				within the Track1Data	
				and Track2Data	
				properties is further	
				separated into fields for	
				access via various other	
				properties. If	
				DecodeData=FALSE,	
				ParseDecodeData must	
				be false.	
TransmitSentinels	boolean	read-write	open	If TRUE, the	Yes

SecuRED OPOS User Manual									
				Track1Data, Track2Data.					
				Track3Data, and					
				Track4Data properties					
				contain start and end					
				sentinel values.					
				Otherwise only the track					
				data between these					
				sentinels.					
TracksToRead	int32	read-write	open	Indicate which track	Yes				
				data that the App wishes					
				to get following a card					
				sweep.					
ErrorReportingType	int32	Read-write	open	Holds the type of errors	Yes				
				to report via					
				ErrorEvents. This					
				property has one of the					
				following values:					
				MSR_ERT_CARD or					
				MSF_ERT_TRACK					

Property Group4---TrackData

Name	Туре	Mutability	Use	Description	Support?
			After		
Track1Data	binary	read-only	open	Holds the track 1 data	Yes
				obtained from the most	
				recently swept card. If	
				DecodeData is true, then it	
				has been decoded from the	
				"raw" format. it may also be	
				parsed into other properties	
				when the ParseDecodeData	
				property is set.	
Track1DiscretionaryD	binary	read-only	open	Holds the track 1	Yes
ata				discretionary data obtained	
				from the most recently swept	
				card. It may be NULL	
				when:	
				1) The field was not included	
				in the track data obtained, or,	
				2) The track data format was	

				not supported, 3)	
				ParseDecodeData is false.	
Track2Data	binary	read-only	open	Holds the track 2 data	Yes
				obtained from the most	
				recently swept card. If	
				DecodeData is true, then it	
				has been decoded from the	
				"raw" format. it may also be	
				parsed into other properties	
				when the ParseDecodeData	
				property is set.	
Track2DiscretionaryD	binary	read-only	open	Holds the track 2	Yes
ata				discretionary data obtained	
				from the most recently swept	
				card. It may be NULL	
				when:	
				1) The field was not included	
				in the track data obtained, or,	
				2) The track data format was	
				not supported, 3)	
				ParseDecodeData is false.	
Track3Data	binary	read-only	open	Holds the track 3 data	Yes
				obtained from the most	
				recently swept card.	
Track4Data	binary	read-only	open	Holds the track 4 data (JIS-II)	No
				obtained from the most	
				recently swept card.	
Track1EncryptedData	binary	read-only	Open	Holds the encrypted track 1	Yes
				data obtained from the most	
				recently swiped card. The	
				start and end sentinel values	
				are contained in it, and	
				appear only after data is	
				decrypted.	
				Encrypted data is always a	
				multiple of 8 bytes (when	
				Encryption Algorithm is	
				3DES) or 16 bytes (when	
				Encryption Algorithm is	
				AES) in length. And it will	
				be transmitted as a Hex	
				string. Example, 0xAB 0x00	
				0x09 is converted to	

				"AB0009".	
Track1EncryptedData	int32	read-only	Open	Holds the length of the raw	Yes
Length			-	track 1 data before it was	
Ŭ				encrypted.	
Track2EncryptedData	binary	read-only	Open	Holds the encrypted track 2	Yes
	2		1	data obtained from the most	
				recently swiped card. The	
				start and end sentinel values	
				are contained in it, and	
				appear only after data is	
				decrypted.	
				Encrypted data is always a	
				multiple of 8 bytes (when	
				Encryption Algorithm is	
				3DES) or 16 bytes (when	
				Encryption Algorithm is	
				AES) in length. And it will	
				be transmitted as a Hex	
				string. Example, 0xAB 0x00	
				0x09 is converted to	
				"AB0009".	
Track2EncryptedData	int32	read-only	Open	Holds the length of the raw	Yes
Length				track 2 data before it was	
				encrypted.	
Track3EncryptedData	binary	read-only	Open	Holds the encrypted track 3	Yes
				data obtained from the most	
				recently swiped card. The	
				start and end sentinel values	
				are contained in it, and	
				appear only after data is	
				decrypted.	
				Encrypted data is always a	
				multiple of 8 bytes (when	
				Encryption Algorithm is	
				3DES) or 16 bytes (when	
				Encryption Algorithm is	
				AES) in length. And it will	
				be transmitted as a Hex	
				string. Example, 0xAB 0x00	
				UXU9 is converted to	
		, .		"AB0009".	37
Irack3EncryptedData	int32	read-only	Open	Holds the length of the raw	Yes
Length				track 3 data before it was	

				encrypted.	
Track4EncryptedData	binary	read-only	Open	Holds the encrypted track 4	No
				data obtained from the most	
				recently swiped card.	
Track4EncryptedData	binary	read-only	Open	Holds the length of the raw	No
Length				track 4 data before it was	
				encrypted.	
AdditionalSecurityInf	binary	read-only	Open	Holds additional	Yes
ormation				security/encryption	
				information when a	
				DataEvent is delivered. For	
				example "DUKPT sequence	
				number" in it.	
				This data is always 10 bytes	
				in length. And it will be	
				transmitted as a Hex string.	
				Example, 0xAB 0x00 0x09 is	
				converted to "AB0009".	
CardAuthenticationD	binary	read-only	Open	Holds card authentication	No
ata				information when a	
				DataEvent is delivered.	
CardAuthenticationD	int32	read-only	Open	This property will be zero if	No
ataLength				CapCardAuthentication is an	
				empty string.	
DeviceAuthenticated	boolean	read-only	Open	If the device supports	Yes
			&	authentication the service	
			Claim	must keep the value of this	
			&	property up to date when the	
			Enabl	device is enabled.	
			e	MSR_SUE_DEVICE_AUTH	
				ENTICATED or	
				MSR_SUE_DEVICE_DEAU	
				THENTICATED.	
CardType	string	read-only	open	Holds the card type identifier	Yes
				for the most recently swiped	
				card. Value is one of them	
				("BANK","AAMVA" and	
				empty).	
CardTypeList	string	read-only	open	Holds a comma separated list	Yes
				of string names of card types	
				supported by the Service.	
				Value is BANK and	
				AAMVA.	

CardPropertyList	string	read-only	open	Holds a comma separated list	Yes
				of the names of the properties	
				parsed from the most recently	
				swiped card.	

Property Group5---ParsedData

Name	Туре	Mutability	Use	Description	Support?
			After		
AccountNumber	string	read-only	Open	Holds the account number	Yes
				obtained from the most	
				recently swept card.	
				it is initialized to NULL if:	
				1) The field was not included	
				in the track data obtained, or,	
				2) The track data format was	
				not supported, or, 3)	
				ParseDecodeData is false.	
ExpirationData	string	read-only	Open	Holds the expiration date	Yes
				obtained from the most	
				recently swept card. Others	
				are same as AccountNumber.	
FirstName	string	read-only	Open	Holds the first name obtained	Yes
				from the most recently swept	
				card. Others are same as	
				AccountNumber.	
MiddleInitial	string	read-only	Open	Holds the middle initial	Yes
				obtained from the most	
				recently swept card. Others	
				are same as AccountNumber.	
Surname	string	read-only	Open	Holds the surname obtained	Yes
				from the most recently swept	
				card. Others are same as	
				AccountNumber.	
Title	string	read-only	Open	Holds the title obtained from	Yes
				the most recently swept card	
				Others are same as	
				AccountNumber.	
Suffix	string	read-only	Open	Holds the suffix obtained from	Yes
				the most recently swept card	
				Others are same as	
				AccountNumber.	

ServiceCode	string	read-only	Open	Holds the service code	Yes
				obtained from the most	
				recently swept card. Others	
				are same as AccountNumber.	

Property Group6--- Statistic

Name	Туре	Mutability	Use	Expected Result	Test
			After		Result
CapStatisticsReporting	boolean	read-write	Open	If true ,the SO can get device information to a XML statistics	No
CapUpdateStatistics	boolean	read-write	Open	If true ,the SO can update the XML statistics	No

Property Group7---Firmware

Name	Туре	Mutability	Use	Expected Result	Test
			After		Result
CapCompareFirmware	boolean	read-write	Open	If true ,the SO can compare the	No
Version				Firmware version	
CapUpdateFirmware	boolean	read-write	Open	If true ,the SO can update the firmware of the device	No
Cap Writable Tracks	Int32	read_only	Open	This capability indicates if the SecuRED device supports the writing of track data - and which tracks are supported.	No
EncodingMaxLength	Int32	read_only	Open	The maximum length of data that can be written by the SecuRED to the track(s).	No
TracksToWrite	Int32	Read-Write	Open	Holds the SecuRED track(s) that will be written.	No
CapDataEncryption	Int32	read_only	Open	Holds a bitwise indication of the encryption algorithms supported by the device and selectable via the	Yes

				DataEncryptionAlgorithm	
				property. MSR_DE_NONE:	
				Data encryption is not enabled.	
				MSR DE 3DEA DUKPT	
				Triple DES Derived Unique	
				Kay Par Transaction	
				MSD DE AES DUKDT	
				MSK_DE_AES_DUKFT	
				(value:3): Advanced	
				Encryption Standard Derived	
				Unique Key Per Transaction.	
DataEncryptionAlgorit	Int32	Read-Write	Open	Holds the encryption algorithm	Yes
hm			&	that will be used to encrypt the	
			Claim	track data. This property may	
				be set to one of the supported	
				encryption algorithms as	
				defined in the	
				CanDataEncryption property	
				MSR DE NONE: Data	
				ancrumtion is not anabled	
Can Trach Data Machin	1 1	Deed outer	0	This wakes will be true if the	Ver
CapTrackDalaMaskin	boolean	Read_only	Open	This value will be true if the	res
g				Service is capable of masking	
		D 1 1		track data.	
CapCardAuthenticatio	string	Read_only	Open	Holds the type, if any, of card	No
n				authentication data that is	
				supported by the device.	
CapDeviceAuthenticati	Int32	Read_only	Open	Holds the level of device	Yes
on				authentication supported by the	
				service.	
				MSR_DA_NOT_SUPPORTE	
				D: The service does not support	
				device authentication.	
				MSR_DA_OPTIONAL: The	
				service supports device	
				authentication but does not	
				require it.	
				MSR_DA_REQUIRED: The	
				service requires device	
				authentication.	
DeviceAuthenticationP	Int32	Read_only	Open	Holds the device authentication	Yes
rotocol		- •		protocol supported by the	
				device. MSR AP NONE: The	
				service does not support device	
	1	1	1	I I I I I I I I I I I I I I I I I I I	1

SecuRED OPOS User Manual								
				authentication.				
				MSR_AP_CHALLENGERESP				
				ONSE: The service supports				
				the challenge response				
				protocol.				
WriteCardType	string	Read-Write	Open	Holds the card type to be used	No			
				the next time the write Tracks				
				method is called.				

2.3. Events of MSR

These events are fired by the Service Object when it is necessary. The following functions are, in fact, the event-handlers that can be added into the applications. Then the applications can receive these events and do some processing accordingly. Please refer to the UnifiedPOS Specification for detailed information.

1) DataEvent

Syntax

void DataEvent (LONG Status);

The *Status* parameter contains the input status. Its value is Control-dependent. And it may describe the type or qualities of the input.

Remarks Fired to present input data from the device to the application.

Description a **DataEvent** can be received when a magnetic card is swiped if the three conditions are all met:

- 1) **DeviceEnabled** = TRUE
- 2) **FreezeEvents** = FALSE
- 3) **DataEventEnabled** = TRUE.

The track data can be obtained, and the parsed data can also be obtained if ParseDecodeData is TRUE.

Support? Yes

2) DirectIO Event

 Syntax
 void DirectIOEvent (LONG EventNumber, LONG* pData, BSTR* pString);

 Parameter Description

 EventNumber
 Event number. Specific values are assigned by the

 Service Object.

pData Pointer to additional numeric data. Specific values vary by *EventNumber* and the Service Object.

pString Pointer to additional string data. Specific values vary by *EventNumber* and the Service Object.

Remarks Fired by a Service Object to communicate directly with the application.

Description The event **DirectIOEvent** is used for some special communication between one SO and an application. Currently, this event is not fully implemented.

Support? No

3) Error Event

Syntax void ErrorEvent (LONG ResultCode, LONG ResultCodeExtended, LONG ErrorLocus, LONG* pErrorResponse);

Parameter Description

ResultCode Result code causing the error event. See **ResultCode** for values.

ResultCodeExtended Extended result code causing the error event. See **ResultCodeExtended** for values.

ErrorLocus Location of the error. See values below.

PErrorResponse Pointer to the error event response. See values below.

When **ErrorReportingType** property is MSR_ERT_TRACK, and *ErrorCode* is E_EXTENDED, then *ErrorCodeExtended* contains Track-level status, broken down as follows:

Byte3 Byte2 Byte1 Byte0

Track 4 Track 3 Track 2 Track 1

Remarks Fired when an error is detected and the Control's **State** transitions into the error state. NOTICE: The error type is only one E_FAILURE (Other or general error) while any error is raised from reading card of SecuRED device. Because the SecuRED hardware cannot support discerning wrong type.

Support? Yes

4) StatusUpdate Event

Syntax void StatusUpdateEvent (LONG Status);

The Status parameter is for device class-specific data, describing the type of status change.

Remarks Fired when a Control needs to alert the application of a device status change.

Note The SecuRED hardware cannot support the notification of power status change.

Description It is not implemented by the SO for the power status cannot be inquired from the SecuRED.

Support? No

3. Programming Examples

There are three simple programming simple examples provided in this section including VC++6.0, VB6.0, and VS2005/2008 C#. The examples include basic operations and event handling.

In general, there are two steps to work with the OPOS control object:

- 1. Insert the OPOS Control Object (CO) into the project
- 2. Add an event handle

3.1. Visual C++ 6.0 Programming Example

Programming Environment:

Windows XP Pro, Visual C++ 6.0, OPOS CO 1.13. ID TECH SO 1.13.307

- 1. Download the OPOS driver and demo from the IDTECH website <u>www.idtechproducts.com</u>. Install the driver and make sure the OPOS demo is functioning.
- 2. In Visual C++ 6.0, create a Dialog Based MFC application using MFC Application Wizard with ActiveX supports.
- 3. Go to Project → Add to Project → Components and Controls. From the "Registered ActiveX Controls" folder, select "OPOS MSR Control 1.13.001", and insert this ActiveX control into the project. An icon for OPOS MSR will be added to the Controls toolbar.

Cont	trols							×	
k	42	Aa	ab	[^{XVZ}]		×	۲		
₽₽	4Þ	\$			0 -	Les	1 1 1 1 1 1	<u>j</u> e	
œ	Ħ	<u>ab</u>	đ		•••	Ð	1	OPOS MSR	

4. Add the OPOS MSR CO to the project dialog.



5. Add DataEvent and ErrorEvent handle

CSecureMagOPOSe VIDC_MSR2	DataEvent ▼	<u></u>
🗇 🎬 👗 ! El 🖑	DataEvent DirectIOEvent	
	ErrorEvent StatusUpdateEvent	
	SecureMag OPOS example	×
 B ⊂ Icon B ⊂ String Table B ⊂ Version 		OK Cancel

void CMfc_diagDlg::OnDataEventMsr1(long Status)

6. Go the View->ClassWizard and select the "Member Variables" tab. Select IDC_MSR and add a member variable of type "COPOSMSR", name it *m_msr*.

MFC ClassWizard						? 🛛
Message Maps	Member Variables	Automation	ActiveX Events	Class Info		
<u>P</u> roject:		Class <u>n</u>	ame:			Add Class 👻 📗
SecureMag OPOS	S example	 CSecur 	eMagOPOSexampl	eDlg 🗾	_	
SecureMag OPOS	exampleDlg.h, Secu	reMag OPOS e	xampleDlg.cpp		$\langle \rangle$	Add Variable
Control <u>I</u> Ds:		Туре	Member			<u>D</u> elete Variable
IDC MSR2		COPOSMSR	l m_msr		Ē	Jodate Columns
IDCANCEL						
						<u>B</u> ind All
Description						
Description.						
					_	
				ОК		Cancel

7. Create a button on the form and add the following initialization code:

```
void CMfc_diagDlg::OnButton1()
{
    if (m_msr.Open("IDTECH_SecuRED_USBKB") == 0)
{
        m_msr.ClaimDevice(100);
        m_msr.SetDeviceEnabled(TRUE);
        m_msr.SetDataEventEnabled(TRUE);
    }
}
```

```
}
else {
    // something wrong ...
}
```

8. Add code for DataEvent handle

```
void CMfc_diagDlg::OnDataEventMsr1(long Status)
{
    MessageBox(m_msr.GetTrack1Data(), "Track 1 data");
    m_msr.SetDataEventEnabled(TRUE); // prepare the next event.
}
```

9. Compile and run the program. Compile and run the program. Click on "Button1" to initialize the reader and swipe a card. Track 1 data will show up in a message box.

SecureMag OPOS example	×
Button1	OK Cancel
B5150710200107747^PAYPASS/MASTERCARD^090910140000866	
	-

3.2. Visual Basic 6.0 Programming Example

Programming Environment:

Windows XP Professional, Visual Basic 6.0, OPOS CO 1.13. ID TECH SO 1.13.307

1. Create a new project of type "Standard EXE".

2. From Project->Components, select "OPOS MSR Control 1.13.001" and click "apply". The OPOS MSR icon will be added to the control toolbar.

General N A Image: A and Im

3. Add an OPOS MSR control to the form. Double click on the control to add "DataEvent" handle.

SecuRED OPOS User Manual



5. Add the code for Event Handle

Private Sub OPOSMSR1_DataEvent(ByVal Status As Long)
MsgBox OPOSMSR1.Track1Data
OPOSMSR1.DataEventEnabled = True
End Sub

6. Run program and swipe a card. The track 1 data will show up in a message box.

<u>.</u>	Project1 - Form1 (Code)		🖻 Form1 📃 🗖 🗙
F	orn 🔽 Load		
	Private Sub Form_Load() OPOSMSRI.Open ("IDTECH EM_USEHID") OPOSMSRI.ClaimDevice (IOO) OPOSMSRI.DeviceEnabled = True End Sub Private Sub Form_Unload(Cancel As Integer) OPOSMSRI.Close End Sub Private Sub OPOSMSRI_DataEvent(ByVal Status As Long) MsgBox OPOSMSRI.TrackIData OPOSMSRI.DataEventEnabled = True		Project 1 X B5150710200107747^PAYPASS/MASTERCARD^090910140000866 OK
		<u> </u>	

3.3. Visual Studio 2005/2008 C# Programming Example

Programming Environment:

Windows XP Professional, Visual Studio 2005/2008 C#, OPOS CO 1.13.001 ID TECH SO 1.13.307

1. Create a "Windows Application" Project.

2. Right click on the "Toolbox" tool bar, select "Choose item …". Under "COM Components" tab, select "OPOS MSR Control 1.13.001" and click okay.

Choose Toolbox Items		?×
.NET Framework Components COM Components WPF Components		
Name Path	Library	
OPOS LineDisplay Control 1.13.00 C:\Program Files\OPOS\CommonCO\	OPOS LineDispl	
OPOS MICR Control 1.13.001 [Pu C:\Program Files\OPOS\CommonCO\ OPOS MotionSensor Control 1.13 C:\Program Files\OPOS\CommonCO\	OPOS MICR Co OPOS MotionSe	
OPOS MSR Control 1.13.001 [Pub C:\WINDOWS\system32\OPOSMSR	OPOS MSR Con	
OPOS PINPad Control 1.10.000 [C:\WINDOWS\system32\OPOSPINPa	OPOS PINPad C	
OPOS PointCardRW Control 1.13 C:\Program Files\OPOS\CommonCO\	OPOS PointCar	
OPOS POSKeyboard Control 1.13 C:\Program Files\OPOS\CommonCO\	OPOS POSKeyb	
OPOS POSPower Control 1.13.00 C:\Program Files\OPOS\CommonCO\	OPOS POSPowe	
OPOS POSPrinter Control 1.13.00 C:\Program Files\OPOS\CommonCO\	OPOS POSPrint	
OPOS RemoteOrderDisplay Contr C:\Program Files\OPOS\CommonCO\	OPOS RemoteO	~
		>
OPOS MSR Control 1.13.001 [Public, by CRM/RCS-Dayton]	Browse	
Language: Language Neutral		
Version: 1.0		
ОК	Cancel <u>R</u> e	eset

3. Add "OPOS MSR Control" to "Form1". Double click on the OPOS MSR Control to add DataEvent handler code. Notice that the device name might need to be changed for different interface.

Toolbox 🚽 🗸	Х	Form1.cs [Design]*	Start Page	▼ ×
F1 HelpProvider	^		_	
🗊 ImageList		Eorm1		
🗇 MessageQueue				
PerformanceCounter		OPOS		
🗔 Process		CRH /RCS		
🔎 SerialPort				
🚟 ServiceController				
🕐 Timer				
🖃 Printing				6
Revinter				
🖽 PageSetupDialog				
🛃 PrintDialog				
🍃 PrintDocument				
A PrintPreviewControl				
🔯 PrintPreviewDialog				
😑 Dialogs				
Revinter				ċ
🗾 ColorDialog				
📑 FolderBrowserDialog				
FontDialog				
🛃 OpenFileDialog	=			
🔚 SaveFileDialog	=			
WPF Interoperability				
😑 General				
Revinter				
MSR OPOS MSR Control 1.13.001 [Public, by	~			

```
private void Form1_Load(object sender, EventArgs e)
       {
          if (axOPOSMSR1.Open("IDTECH_SecuRED_USBKB") == 0)
            //0 is OPOS SUCCESS
          {
             axOPOSMSR1.ClaimDevice(100);
             axOPOSMSR1.DeviceEnabled = true;
             axOPOSMSR1.DataEventEnabled = true;
          }
      }
      private void axOPOSMSR1 DataEvent(object sender,
AxOposMSR_1_13_Lib._IOPOSMSREvents_DataEventEvent e)
      {
         MessageBox.Show(axOPOSMSR1.Track1Data, "Track 1 data");
          axOPOSMSR1.DataEventEnabled = true;
      }
```

4. Run the program and swipe a card. Track 1 data will be displayed in a window.



4. Result Code/Error Code List

const	LONG	OPOS	_St	JCCESS	=	0;
const	LONG	OPOS	_E_	CLOSED	=	101;
const	LONG	OPOS	_E_	_CLAIMED	=	102;
const	LONG	OPOS	_E_	NOTCLAIMED	=	103;
const	LONG	OPOS	_E_	NOSERVICE	=	104;
const	LONG	OPOS	_E_	DISABLED	=	105;
const	LONG	OPOS	_E_	ILLEGAL	=	106;
const	LONG	OPOS	_E_	NOHARDWARE	=	107;
const	LONG	OPOS	_E_	OFFLINE	=	108;
const	LONG	OPOS	_E_	NOEXIST	=	109;
const	LONG	OPOS	_E_	EXISTS	=	110;
const	LONG	OPOS	_E_	FAILURE	=	111;
const	LONG	OPOS	_E_	TIMEOUT	=	112;
const	LONG	OPOS	_E_	BUSY	=	113;
const	LONG	OPOS	_E_	EXTENDED	=	114;